



# DISHWASHER TABLETS FINISH ULTIMATE ALL IN 1

FOR A DEEP CLEAN



Finish ULTIMATE All in 1, for a deep clean and sparkling shine 1st time, every time. Its compact 3-chamber chemistry is effective at breaking down all types of food residues - even without pre-rinsing. With 30% less chemical weight than Finish's traditional pressed powder tablets.\*

\*Vs, Finish Power All in 1.



Save water  
No pre-rinse



Clean  
dish



Shiny  
glass



Eco  
cycle



1st time tough  
stain removal

TO BOOST YOUR DISHWASHING EXPERIENCE, WE RECOMMEND:

1



RINSE AND  
SHINE AID  
FOR DRIER AND  
SHINIER DISHES

2



DISHWASHER  
DEEP CLEANER  
FOR A CLEAN  
DISHWASHER

3

## DESIGNED FOR

Suitable for  
all Dishwashers

Excellent for Office Kitchenettes



## INFORMATION

SKU Code	Tabs	Variant
3207989	36	Fresh Burst
3204880	100	Lemon Sparkle
3207986	18	Lemon Sparkle
3207987	36	Lemon Sparkle
3205913	50	Lemon Sparkle
3204879	72	Lemon Sparkle

## DIRECTIONS

1. Handle with dry hands only. 2. Do not pierce break, cut or tear pouches apart. Always reseal pack after use. 3. No unwrapping. Dissolves completely in wash. 4. Place one tab per wash in the DRY dispenser. No need to pre-rinse. Remove food scraps and scrape plates & dishes. Load dishes with soiled surfaces facing the water sprays. 5. Don't place in cutlery basket. EXCEPT FOR FISHER & PAYKEL DISHDRAWER®, if it does not fit in dispenser place it in an empty section of the cutlery basket. 6. For best results use 50-55°C or eco/auto cycles. Suitable for short cycles.

USAGE ADVICE: The built-in salt function is effective in soft/medium & hard water up to 370ppm of hardness. To protect the quality of the Ultimate tabs, always reseal the pack after use and store away from heat and moisture.



RECOMMENDED BRAND\*\*

beko

BOSCH

DeLonghi

LG

Midea

SIEMENS

smeg

\*\*Finish is recommended by renowned dishwasher manufacturers.